

# NIMBUS DAILY READING AND RESETTING INSTRUCTIONS



The Nimbus Max/Min digital thermometer remembers the highest and lowest temperatures for the period since it was last reset.

**To determine the maximum and minimum readings, push the Recall button to the right of the display and hold it.** The display will alternate between the highest temperature and the lowest temperature since last reset.

Once the high and low are noted, as well as the current temp, reset the display. **To reset the display, push the Clear button and wait for about 6 seconds until “E2E.2” is displayed.** This signals the unit has been reset.

If you were to press the recall button right after you have reset the unit both the max and min readings would be the same.

...Refer to the instruction manual for additional information...

National Weather Service Contacts: Kimberly Buttrick or  
William Simpson

National Weather Service  
445 Myles Standish Blvd.  
Taunton, MA 02780  
800-243-1686 or  
508-823-2262

Email: [Kimberly.Buttrick@noaa.gov](mailto:Kimberly.Buttrick@noaa.gov)

[William.Simpson@noaa.gov](mailto:William.Simpson@noaa.gov)